

Mealtime chairs



Removable tray

is made of durable, dishwasher-safe, cream-coloured, scratch-resistant plastic.

Removable seat belt

has a unique child-proof clip.



Removable, washable insert has a contoured post and tray latches moulded right in. And you can put it away when children outgrow the need for a post or tray.

For ages 6 months to 24 months

20 cm Mealtime chair J436

Specify seat insert colour, lilac or latte.



20 cm Mealtime chair with tray J437

Specify seat insert colour, lilac or latte.



25 cm Mealtime chair J434

Specify seat insert colour, lilac or latte.



25 cm Mealtime chair with tray J435

Specify seat insert colour, lilac or latte.



Everything stacks:

the chairs stack with or without the seat insert in place.

Chair dolly J413

Childshape chairs

20 cm Childshape chair J408

25 cm Childshape chair J410

30 cm Childshape chair J412

Chair dolly J413

Seat belt J439

Replacement chair tips J426

(Set of 12)



Dimensions (cm)	20 cm chair	25 cm chair	30 cm chair
Seat height	20	25	30
Seat width	25	28	29
Seat depth	18	23	25
Armrest height	33	38	43

Sound-dampening chair tips

reduce noise.